



1. Fabricate a 6-wire AWG24 shielded bundle long enough to reach between the ELT installation location and the cockpit panel RCP and GPS equipment location.
2. Fit the ELT / [On board GPS+RCP] cable with a S1820514-03 DIN-12 male connector (P3) on the DONGLE IF GPS side.
3. Fit the cable with a mating connector P4 according to J2 RCP connector type (See NOTE below).

NOTE: RCP mating connectors and relevant RCP pin-out inputs are defined in the IF-GPS Description Installation and Operations Manual" ref. DOC11038. For complete instructions and specifications, this manual can be found on Kannad Aviation download area.